



K Lite Kit User Manual

Read this information leaflet fully before you start using this product as it contains important information. The notes below relate to when the device is filled with e-liquid that contains nicotine.

This product is intended for adult smokers. This product is not recommended for non-smokers, young people under the legal age, pregnant or breast feeding women and those experiencing general ill health.



Pack Contents:

- 1* K Lite mod
- 1* K Lite tank
- 2* Nichrome coils (1.6Ω & 1.8Ω preinstalled)
- 1* USB cable
- 1* Warranty card
- 1* User manual

Tank Features

Easy top fill
2ml capacity
Adjustable airflow
Coil resistance:
1.6Ω (3.0-4.2V) (6-11W)
1.8Ω (4.2-5.0V) (9-13W)
Coil material: Nichrome
Tank is compatible with aspire original BVC coils and Spryte coils
Diameter: 16mm
Length (including drip tip): 57mm

Tank Filling

1. Unscrew the top hardware and remove it from the tank;
2. Add your preferred e-liquid by pushing the tip of your filling bottle through the filling hole;
3. Put the top hardware back on top of the tank then screw to secure it.



- When installing a new coil, let the tank stand for 5 minutes after filling so the cotton can be saturated with e-liquid before use.
- Do not let the tank become completely empty. Refill the tank to avoid dry burning or damage to the coil.

1

Coil Installation

1. Invert the tank, unscrew to disengage the base hardware;
2. Unscrew to remove the used coil and replace with a new one;
3. Screw in to relocate the base hardware.



Mod Specifications

Optional output voltage: 3.0V, 3.5V, 4.0V, 4.5V, 5.0V
Supported resistance range: 0.8-3.0Ω
Continuous firing time: 10 seconds
Firmware update: N/A
Battery type: Built-in LiPo
Battery capacity: 900mAh
Dimensions: 26.5*75*17mm

Instructions

- **Power on/off**
Pressing the fire button 5 times within 2 seconds will turn the device on or off. The indicator light will flash white 3 times to indicate on or off.
- **Vaping**
When the device is on, press the fire button, the indicator light will indicate your device's current charge. When its current charge is above 3.8 volts (60-100%), the indicator light will be green. When the charge is between 3.5 and 3.8 volts (30-60%), the light will be blue. When the charge drops below 3.5 volts (0-30%), the light will then turn red to remind you that it is time to charge the device.
- **Set the output voltage**
Press the mode button to adjust the output voltage. The voltage display will turn on for 3 seconds to indicate the value of the corresponding output voltage: 3.0V, 3.5V, 4.0V, 4.5V, 5.0V.

2

Protection Features

- Automatic cutoff: The preset continuous fire time is 10 seconds, after 10 seconds of continuous firing, the indicator light will flash pink 10 times and the device will stop firing.
- Short circuit protection: When the device detects a short, it will stop firing, and the indicator light will flash pink 3 times.
- Low voltage protection: When the battery level drops below 3.0V, the device will not function and the indicator light will flash red 15 times to remind you to charge the device.
- Overcharge protection: When the device is fully charged, it will stop charging to prevent overcharging of your battery.
- Over heat protection: When the temperature of the chip is above 75 °C/167 °F, the indicator light will be yellow for 3 seconds and the device will cut off.

Charging Instructions

- Charging the device via Micro USB charging port, the maximum current can reach up to 1A, and the recommended charging voltage is 5.0V.
- When the USB cable is attached, the indicator light will flash red 3 times. While charging, the indicator light will indicate the device's current charge status: 3.5 volts or less (0-30%) = red light; 3.5 to 3.8 volts (30-60%) = blue light; 3.8 volts and above (60-100%) = green light. When the device is fully charged, the indicator light will flash green 20 times then remain off. When unplug the USB cable, the indicator light will flash green 3 times.

IMPORTANT INFORMATION ABOUT USING NICOTINE CONTAINING E-LIQUIDS

Before using nicotine containing e-liquids the user should read the following information carefully.

NICOTINE CONTAINING E-LIQUIDS:

Do not use if you are allergic to nicotine or any of the other ingredients contained within the e-liquid (see manufacturer's label for full details).

WARNINGS AND PRECAUTIONS

- Nicotine containing e-liquids are not recommended for:
 - Non-smokers

3

- Young people under the legal age;
- Pregnant or breast feeding women; as nicotine is known to cross the placenta and to be excreted in breast milk;
- Those experiencing general ill health; such as heart disease, stomach and duodenal ulcers, liver or kidney problems, long term throat disease or difficulty breathing due to bronchitis, emphysema or asthma;
- Those who have an overactive thyroid gland or have a pheochromocytoma (a tumour of the adrenal gland that can affect high blood pressure);
- Those who have diabetes, as nicotine may affect your blood sugar levels.
- Those taking the following medication:
 - Theophylline (to treat breathing problems)
 - Ropinirole (to treat restless leg syndrome)
 - Clozapine (to treat schizophrenia)

POSSIBLE SIDE EFFECTS

If you inhale too much nicotine or use the product too much you may experience one or more of the following effects:

- Feeling faint;
- Nausea (feeling sick)
- Headache
- Coughing
- Irritation of the mouth or throat
- Dizziness
- Stomach discomfort
- Hiccups
- Nasal congestion
- Vomiting (being sick)
- Heart palpitations
- Abnormal heart rate

If you experience any of these side effects; including any possible side effects not listed in this leaflet, discontinue using the product, if the effect(s) continue after you stop use, consult your doctor or healthcare professional and bring this leaflet to their attention.

Safety note:

To avoid misfiring always ensure you either lock or switch off your device when it is not in use. Especially when carrying your device in your pocket, bag or purse.

4

To learn more about your products and how to use, please visit: www.aspirectg.com

Shenzhen Eigate Technology Co., Ltd.

Building 3, Xinhongtai Industrial Park, 14 Jian'an Rd, Tangwei, Fuyong Town, Bao'an District, Shenzhen, China
Tel: +86-755-81499783 Email: service@aspirectg.com

Manufactured By Eigate MADE IN CHINA



5